



Danfoss


INSTRUCTIONS

Gland seal for RA-C valve




013R9292

1)



2)



013R9292

- UNIDOMO®**
- Ⓚ Kan udskiftes under drift. Husk tæthedskontrol.
 - ⓖ Can be replaced during operation. Don't forget leak inspection.
 - ⓓ Während des Betriebs auswechselbar. Dichtigkeitskontrolle nicht vergessen.
 - ⓕ Le remplacement peut se faire en cours de marche. Penser au contrôle d'étanchéité.
 - Ⓢ Kan bytas under drift. OBS - tåthetskontroll.
 - Ⓝ Kan tijdens bedrijf vervangen worden. Vergeet niet op dichtheid te controleren.
 - ⓕ Voidaan vaigtaa käytön aikana. Muista tiiviyskoe.

DKCD

01-2000 VI.36.A1.6J



Web: www.unidomo.de

Telefon: 04621- 30 60 89 0

Mail: info@unidomo.com

Öffnungszeiten: Mo.-Fr. 8:00-17:00 Uhr

VIESSMANN



 **Vaillant**

WOLF

 **JUNKERS**  **BOSCH**

 **remeha**

 **DAIKIN**

ROTEX
a member of DAIKIN group



-  Individuelle Beratung
-  Kostenloser Versand
-  Hochwertige Produkte

-  Komplettpakete
-  Über 15 Jahre Erfahrung
-  Markenhersteller