



013R9319

013R9319

- (DK) Anlæg
(GB) Systems
(D) Anlagen

- (F) Système
(NL) Installatie
(S) Anläggning

- (FIN) Järjestelmät
(PL) Zastosowanie




- (DK) Blandekreds på gulvvarmeanlæg.
(GB) Floor-heating system.
(D) Fussboden-Mischkreis.
(F) Système de chauffage au sol.
(NL) Menginjectie-systeem in vloerverwarming
(S) Blandningskrets i golvvärmeanläggning.
(FIN) Lattialämmitysjärjestelmä.
(PL) Ogrzewanie podłogowe.


- (DK) Blandekreds på radiator- eller gulvvarmekreds med veksler.
(GB) Heat exchanger in radiator heating or floor heating system.
(D) Wärmetauscher-Regelung für Heizkörper- und Fussbodenheizung.
(F) Echangeur thermique dans un système de chauffage par radiateur ou au sol.
(NL) Warmtewisselaar in radiator- of vloerverwarming-systeem.
(S) Blandningskrets i radiator- eller golvvärmekrets med värmeväxlare.
(FIN) Lämmönvaihdin radiaattori- tai lattialämmitysjärjestelmässä.
(PL) Wymiennik ciepła w instalacji z grzejnikami lub podłogowej.

UNIDOM

- (DK) Montage af termostatisk element
(GB) Mounting of thermostatic head
(D) Montage von Thermostatkopf
(F) Montage de la tête thermostatique
(NL) Montage van regelement
(S) Montering av regulatorordel
(FIN) Termostaatin asennus
(PL) Mocowanie głowicy termostatycznej



- (DK) Montage af fjernføler
(GB) Mounting of remote sensor
(D) Montage von Fernfühler
(F) Montage du capteur à distance
(NL) Montage van afstandsvoeler
(S) Montering av lös givare
(FIN) Anturin asennus
(PL) Mocowanie zdalnego czujnika





Web: www.unidomo.de

Telefon: 04621- 30 60 89 0

Mail: info@unidomo.com

Öffnungszeiten: Mo.-Fr. 8:00-17:00 Uhr

VIESSMANN



 **Vaillant**

WOLF

 **JUNKERS**  **BOSCH**

 **remeha**

 **DAIKIN**


ROTEX
a member of DAIKIN group




-  Individuelle Beratung
-  Kostenloser Versand
-  Hochwertige Produkte

-  Komplettpakete
-  Über 15 Jahre Erfahrung
-  Markenhersteller

- ⒹⓀ Max. begrænsning
- ⒼⒷ Max. limitation
- Ⓓ Max. Begrenzung
- Ⓕ Limite max.
- ⓃⓁ Max. begrenzing
- Ⓢ Max begränsning
- ⒻⒿ Maksimirajoitus
- Ⓟ Maks. ustawienie graniczne



- ⒹⓀ Min. begrænsning
- ⒼⒷ Min. limitation
- Ⓓ Min. Begrenzung
- Ⓕ Limite min.
- ⓃⓁ Min. begrenzing
- Ⓢ Min begränsning
- ⒻⒿ Minimirajoitus
- Ⓟ Min. ustawienie graniczne



 UNIDOMO®