


D Montageanweisung
F Instructions d'installation
I Istruzioni di montaggio
NL Installatievoorschrift
DK Installationsinstruktus
N Installationsinstruktioner
FIN Asennusohje
S Installation instruktioner
E Instrucciones de montaje


ML6420A30xx/ML7420A60xx

Electric Linear Valve Actuators


INSTALLATION INSTRUCTIONS




A1-A6: Installation




A1




A2




A3



A4a: ML6420A3007, A3023 (24 V)



A4b: ML6420A3015, A3031 (230 V)






Ihr Online-Fachhändler für:

- Kostenlose und individuelle Beratung
- Hochwertige Produkte
- Kostenloser und schneller Versand
- TOP Bewertungen
- Exzelerter Kundenservice
- Über 20 Jahre Erfahrung




E-Mail: info@unidomo.de | Tel.: 04621 - 30 60 89 0 | www.unidomo.de


A4c: ML7420A6009, A6017 (0/2...10 V)




A5a: ML7420A6009, A6017 (0/2...10 V)




A5b: ML7420A6009, A6017 (0/2...10 V)




A5c: ML7420A6009, A6017 (0/2...10 V)




A6




B: Manual




C1-2: Dismounting



C1



C2



Home and Building Technologies

Honeywell GmbH
Böblinger Strasse 17
71101 Schönaich
Germany

Phone: (49) 7031 637 01

Fax: (49) 7031 637 740

<http://ecc.emea.honeywell.com>

Subject to change without notice. Printed in Germany

MU1B-0234GE51 R0216E