



- 1 - B 961716 XX
- 2 - B 960473 XX
- 3 - B 961438 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - A 861156 NU
- 7 - E 960059 NU
- 8 - A 960935 XX
- 9 - A 964520 NU
- 10 - A 962991 XX
- 11 - A 962005 NU
- 12 - B 961119 XX



09.2023 / B565133



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>





Ihr Online-Fachhändler für:

- Kostenlose und individuelle Beratung
- Hochwertige Produkte
- Kostenloser und schneller Versand
- TOP Bewertungen
- Exzelerter Kundenservice
- Über 20 Jahre Erfahrung



E-Mail: info@unidomo.de | Tel.: 04621 - 30 60 89 0 | www.unidomo.de



1 Turning the cartridge to the 'H' position.

2 Turning the cartridge to the 'C' position.

Warnings:

- Do not use the cartridge to turn the faucet on/off.

P	T	MAX. 80	Q (3 bar)					
			0	1	2	3	4	5
0,3 MPa 3 bar	50°C	15°C	50	49	44	40	35	33
	65°C	15°C	65	63	57	50	44	40
	85°C	15°C	85	83	74	64	56	50

	P	bar		MAX. 10		5			I/min	6
	T	°C		MAX. 80		65				