






A DN 30 - 50




B DN 70 - 100



1



2





Web: www.unidomo.de

Telefon: 04621- 30 60 89 0

Mail: info@unidomo.com

Öffnungszeiten: Mo.-Fr. 8:00-17:00 Uhr

VIESSMANN



 **Vaillant**

WOLF

 **JUNKERS**  **BOSCH**

 **remeha**

 **DAIKIN**

ROTEX
a member of DAIKIN group



-  Individuelle Beratung
-  Kostenloser Versand
-  Hochwertige Produkte

-  Komplettpakete
-  Über 15 Jahre Erfahrung
-  Markenhersteller

3

max. 10 mm

10 mm

2

4





Diagram 4 illustrates the final step of mounting the front plate. The front plate is shown being aligned with the side plate. A red arrow indicates the direction of movement. A warning symbol (exclamation mark in a triangle) is shown next to the front plate, indicating a caution step.

5



0 mm

max 55 mm

6




Diagram 6 shows the door being attached to the frame. The door is shown in a partially open position, with a red arrow indicating the direction of movement. The door has a label "VIERER-GEHÄUSE" on the top edge. The frame is shown in a partially open position, with a red arrow indicating the direction of movement.

7 **4x**

1

2

6

8 **4x**

This diagram shows the door hinge assembly being tightened. A screwdriver is shown turning a screw on the right hinge. Red arrows indicate the direction of tightening for all four screws on both hinges. A callout box in the top left corner shows a close-up of the screw and the quantity '4x'.

Diagram 9 shows the front panel being attached to the side panel. A red arrow labeled '1' points to the bottom edge of the front panel, indicating it should be pushed into the side panel. Another red arrow labeled '2' points upwards along the right edge of the front panel, indicating it should be pushed into the top of the side panel.