


SCHELL WC-Betätigungsplatte



ⓓ **Montageanleitung WC-Betätigungsplatte**

Funktion: START / STOPP

Art.-Nr. 03 262 28 99

ⓃⓁ **Montagevoorschrift WC-bedieningsplaat**

Functie: START / STOP

Art.-nr. 03 262 28 99

ⓕ **Notice de montage**

Plaque de commande pour WC

Fonction: MARCHÉ / ARRÊT

Réf. 03 262 28 99

ⓖⓑ **Assembly instructions for WC-Activation plate, Function: start / stop**

item no. 03 262 28 99

ⓔ **Instrucciones de Montaje Escudo WC**

Funcion: start / stop

Art. No. 25 03 262 28



Web: www.unidomo.de

Telefon: 04621- 30 60 89 0

Mail: info@unidomo.com

Öffnungszeiten: Mo.-Fr. 8:00-17:00 Uhr

VIESSMANN



 **Vaillant**

WOLF

 **JUNKERS**  **BOSCH**

 **remeha**

 **DAIKIN**

ROTEX
a member of DAIKIN group



Individuelle Beratung



Kostenloser Versand



Hochwertige Produkte













Komplettpakete



Über 15 Jahre Erfahrung



Markenhersteller



SCHELL GmbH & Co. KG
 Armaturentechnologie
 Postfach 1840
 D-57448 Olpe
 Tel.: ++49 27 61-8 92-0
 Fax: ++49 27 61-8 92-1 99
 info@schell.eu
 www.schell.eu