

Fig. 1

de Einbau- und Betriebsanleitung
 en Installation and operating instructions
 fr Notice de montage et de mise en service
 nl Inbouw- en bedieningsvoorschriften
 es Instrucciones de instalación y funcionamiento
 it Istruzioni di montaggio, uso e manutenzione
 pt Manual de instalação e funcionamento
 el Οδηγίες εγκατάστασης και λειτουργίας
 tr Montaj ve kullanma kılavuzu
 sv Monterings- och skötselanvisning
 no Montasje- og bruksanvisning
 fi Asennus- ja käyttöohje
 da Monterings- og driftsvejledning
 hu Beépítési és üzemeltetési utasítás
 pl Instrukcja montażu i obsługi
 cs Návod k montáži a provozu
 ru Инструкция по монтажу и эксплуатации
 et Paigaldus- ja kasutusjuhend
 lv Uzstādīšanas un ekspluatācijas instrukcija
 lt Montavimo ir naudojimo instrukcija
 sk Návod na montáž a obsluhu
 sl Navodila za vgradnjo in obratovanje
 bg Инструкция за монтаж и експлоатация
 ro Instrucțiuni de montaj și exploatare
 hr Upute za ugradnju i uporabu
 sr Uputstvo za ugradnju i upotrebu
 uk Інструкція з монтажу та експлуатації





www.wilo.com/automation




www.wilo-recycling.com

Fig. 2



UNIDOMO®

Fig. 3





Web: www.unidomo.de

Telefon: 04621- 30 60 89 0

Mail: info@unidomo.com

Öffnungszeiten: Mo.-Fr. 8:00-17:00 Uhr

VIESSMANN



 **Vaillant**

WOLF

 **JUNKERS**  **BOSCH**

 **remeha**

 **DAIKIN**

ROTEX
a member of DAIKIN group



Individuelle Beratung



Kostenloser Versand



Hochwertige Produkte



Komplettpakete



Über 15 Jahre Erfahrung



Markenhersteller

Wilo-IF-Modul Stratos PLR

Fig. 4



1 x IF-Modul Stratos PLR



Wilo-Stratos/Stratos-Z




Fig. 5



2 x IF-Modul Stratos PLR



Wilo-Stratos/Stratos-D/Stratos-Z/Stratos-ZD

